



EZ-Ject™ Soil Injector Parts Chart



Ref	Part No.	Description
1	S101	Handle Grip (2 per injector)
2	S102	Handle (2 per injector)
3	S103	Hitch Pin (2 per injector)
4	S104	Body
5	S105	Release Lever Grip
6	S106	Coupler Complete (Includes #7)
7	S107	Coupler O-Ring
8	S108	Check Valve (2 per injector)
9	S109	Piston (Includes 1-#10, 2-#11)
10	S110	Piston O-Ring

Ref	Part No.	Description
11	S111	Piston Backer Ring (3 per injector)
12	S112	Sleeve
23	†	Piston Cylinder
13	S113	Probe O-Ring
14	S114	Probe (Includes #13)
15	S115	Foot Plate (Includes #16)
16	S116	Foot Plate Screw
17	S117	Tip
18	S118	Coupler Spacer
19	S119	Check Valve O-Ring

Ref	Part No.	Description
20	S500	Tank Complete (Includes #21, #22)
21	S501	Tank Cap
22	S502	Tank Stand
*	SK01	Seal Kit (Includes: #7, #10, 2-#11, #13, 3-#19)
24	S120	Check Valve with restrictor (Includes #19)
25	S503	Wrench Set
26	S504	Garden Hose Adapter

* Not Shown † Not Available Separately